



**R&S LEAFSPRING**

A = Length A along leaf surface  
 B = Length B along leaf surface  
 C = Free Open (Arch), length from center bolt to line going from center eye to center of eye  
 D = Thickness of spring  
 E = Free Length, from center of eye to center of eye straight across